

# TEKTITE®

*Demanding Environments... Rugged Gear™*

309 N. Clinton Avenue · Trenton, NJ 08638-5122 · Telephone: 1-800-540-2814 / 609-656-0600

Website: [www.tek-tite.com](http://www.tek-tite.com) · E-mail: [info@tek-tite.com](mailto:info@tek-tite.com)

## **SOSeFLARE™**

### **High-Intensity USCG eVDS LED Distress Beacon**

MFG P/N 2C-1005

- Lamp: High-intensity LED-strobe for high visibility marking or distress
- Burn Time: 30+ hours of battery life from 3 - CR123 cell Lithium-Alkaline batteries
- Flash rate: Morse code S-O-S flashes 4 times per minute.
- Materials: ABS and LEXAN®
- Visible for up to 10 miles (conditions permitting)
- Waterproof; dive rated to 500 feet (150 m)
- Lamp Life: 10,000+ Hours
- Twist on, rotary switch
- Lanyards included
- Made in the U.S.A.\*  
\*complies with the "Buy American Act", may contain imported components.

#### **Operation of the SOSeFLARE™:**

1. Batteries are pre-installed. To turn on, hold the strobe body in one hand and turn lens clockwise until the light turns on. Observe the ON/OFF Marks and arrows on rim under the clear lens.
2. To turn off, turn lens counterclockwise and **continue to turn it one full turn** after the light is extinguished. This prevents the light from coming on accidentally.

#### **If Your Strobe Floods:**

1. Remove and discard batteries.
2. Flush flashlight and parts with warm, fresh water.
3. Dry, then check for damage or corrosion.
4. Return to factory or replace damaged parts as necessary.

#### **General Strobe and Battery Information:**

- **Batteries:**  
For maximum brightness and burn time, we recommend Ultralife CR123 cell Lithium-Alkaline batteries. Install all batteries with the positive (+) end up, facing up out of the light.
- Check operation momentarily before each trip. Replace batteries every 5 years for safety.

#### **Proper Use:**

Strobe electronics can fail if not properly handled; the LED strobe module contains delicate electronics.

Refrain from dropping, banging or otherwise jolting this strobe. Cushion strobe during transport and storage to prevent breakage due to vibration and unintentional jolting.

#### **Maintenance:**

Occasionally clean and lightly lubricate lens threads and O-rings with silicone grease. Never use aerosol spray lubricants.

#### **Caution:**

Remove batteries from strobe during periods of storage to prevent damage from cell leakage.

Do not look at the flashing light. Eye damage can occur from prolonged exposure.

#### **Limited Lifetime Warranty:**

Tektite guarantees that its products are free from defects in material and workmanship for the normal life of the product. This warranty includes LEDs; and excludes O-rings, Lanyards, Batteries, Bulbs and strobe electronics, which are wear items; these items are covered for 60 days from date of purchase, or their normal service life as stated on the package, whichever comes first. This warranty is to the original owner only, and does not cover damage due to normal wear, abuse, alteration, poor maintenance, accidents, loss or negligence. Our liability is strictly limited to repair or replacement of the product.

To make Warranty effective, the original purchaser must return the damaged unit to Tektite, postage paid, together WITH PROOF OF PURCHASE AND \$9.00 FOR S+H. ALL APPLICABLE IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE, GIVEN TO YOU BY LAW ARE HEREBY LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. UNDER NO CIRCUMSTANCES WILL TEKTITE BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.

(Some States do not allow limitations on how long an implied warranty lasts, or the exclusion of incidental or consequential damages, so the above limitations may not apply to you and you may also have other legal rights which vary from State to state beyond the rights created by this Warranty.) The Manufacturer neither assumes nor authorizes any other person to assume for it any other liability than stated herein.

